



Application Guidelines Powercrete® Spray Equipment Part A and Part B Ratio Checks

1. Warm part A and part B to spray temperature.
2. Take ratio check at the end of hose bundle, with valves for A and B line.
3. Use a 1000 ML beaker for Part A, mark 1A, 2A, and 3A. Use a 250 ML beaker for Part B, mark 1B, 2B, and 3B. Mark the weight of tare on the beakers, and arrange the beakers pair by pair next to each other in two parallel lines.
4. Turn on King Pump to low-pressure 20 psi ±.
5. Set A valve on A beaker and B valve on B beaker, open the valves and let materials flow smoothly.
6. Partially close the valves to achieve equal or close pressure on both A and B.
7. When the pressure is quite close, listen to the King Pump's up and down stroke sound.
8. Collect Part A and Part B at the same time into the tared and graduated beakers with the help of the sound which pops when the king motor changes direction (up/down).
9. Count one for the next sound.
10. Collect 8 or 10 sounds, even sounds.
11. Weigh material and mark the weight, mark the volume in millimeters.
12. The ratio to be obtained:

A:By Weight

Powercrete:	$\frac{\text{Weight of B}}{\text{Weight of A}} = 0.055 \pm 0.002$
Powercrete "J":	$\frac{\text{Weight of "J" B}}{\text{Weight of "J" A}} = 0.112 \pm 0.002$
Powercrete "J" Fast Cure:	$\frac{\text{Weight of "J" Fast Cure B}}{\text{Weight of "J" Fast Cure A}} = 0.152 \pm 0.002$
Powercrete "J" Flex:	$\frac{\text{Weight of "J" Flex Part B}}{\text{Weight of "J" Flex A}} = 0.148$

B:By Volume

Powercrete:	$\frac{\text{Volume of A in ML}}{\text{Volume of B in ML}} = 9.75$
Powercrete "J":	$\frac{\text{Volume of A}}{\text{Volume of B}} = 4.80$
Powercrete "J" Fast Cure:	$\frac{\text{Volume of A}}{\text{Volume of B}} = 4.0$
Powercrete "J" Flex:	$\frac{\text{Volume of A}}{\text{Volume of B}} = 4.15$

NOTE: Weight ratio is much more accurate than volume ratio.

Headquarters:

Tyco Adhesives L.P.
 1400 Providence Hwy
 Norwood, MA 02062 USA
 Int'l Tel: +1 781 440-6161
 US Toll Free: +1 800 248-0149
 Fax: +1 781 440-6271
 E-mail: CPG@tycoadhesives.com

In the Americas:

Tyco Adhesives
 1675 Suite C Brandywine Avenue
 Chula Vista, CA 91911 USA
 Tel: Mexico +52 664 623 30 70
 Tel: US +1 619 4 24 42 59
 Fax: Mexico +52 664 623 64 63
 Fax: US +1 619 4 24 42 58
 E-mail: CPGTJ@tycoadhesives.com

Tyco Adhesives (Houston)
 11010 Wallisville Road
 Houston, TX 77013 USA
 Tel: +1 713 676 0085
 US Toll Free: +1 888 676 7202
 Fax: +1 713 676 0086
 E-mail: CPGH@tycoadhesives.com

In Europe, Middle East, Africa,

Asia & Pacific:
 Tyco Adhesives B.V.B.A.
 Nieuwlandlaan B15
 B-3200 Aarschot, Belgium
 Tel: 32 16 55 36 00
 Fax: 32 16 55 36 74
 E-mail: CPGE@tycoadhesives.com

Tyco
Adhesives

Corrosion Protection Group
The common denominator in Corrosion Prevention
www.TycoAdhesives.com

Local agent/Distributor:

AG-PC-SPRAY REV.1-02/03